



Structural Systems

QUANTOM® Wrap 200A



Structural

QUANTOM® Wrap 200A

Aramid Fiber Fabric for Structural Strengthening Systems

Description

QUANTOM® Wrap 200A is a unidirectional Aramid fiber fabric. When used in conjunction with QUANTOM® EPR3001 or QUANTOM® EPR3301 epoxy laminating resin, the system can provide a dry lay-up or wet lay-up applied composite strengthening system.

Where to Use

Strengthening of reinforced concrete structures, masonry and timber, structural elements on structures such as bridges, parking structures, marine structures, chimneys, silos, tunnels and tanks, pipelines, etc.

Loading increase

- Increasing the live loads in warehouses.
- Increased traffic volumes on bridges.
- Installation of heavy machinery in industrial buildings and vibrating structures.
- Change in building use.

Seismic strengthening

- Column wrapping.
- Shear Strengthening.
- Flexural strengthening.
- Masonry walls out of plane bending prevention.

Damage to structure parts

- Aging of RC structures.
- Aging of construction materials.
- Vehicle impact.
- Fire.

Change in structural system

- Removal of walls or columns.
- Removal of slab sections for openings.

Design or construction defects

- Insufficient reinforcements.
- Insufficient structural ductility.

Advantages

- Very thin layer ideal for confined spaces.
- Dry lay-up.
- Use for shear, confinement or flexural strengthening.
- Flexible, can be wrapped around complex shapes.
- High strength.
- Light weight.
- Non-corrosive.
- Alkali resistant.
- Low aesthetic impact.

| Description | First Coat | Inter-Layer Coat |
|-------------------|---------------|------------------|
| Resin Consumption | 1.0-1.2 Kg/M2 | 0.8 - 1.0 Kg/M2 |

Shelf Life

Resins: 2 years in original, unopened packaging.
 Store dry at 15° - 25°C (41° - 77°F).
 Condition product to 18° - 24°C (65° - 75°F) before using.
 Fabric: Unlimited, store dry at 5° - 32°C (41° - 89°F).

Fiber Properties

Primary fiber direction: 0° Unidirectional
 Tensile strength: 2800 MPa
 Tensile E-modulus: 110 GPa
 Elongation: 2.0%
 Density: 2.86 Gr/Cm3
 Areal weight: 200 Gr/m2
 Thickness: 0.140 mm

How to Use

Surface Preparation: Prepare the surface by sandblasting or grinding. Remove any dust or loose particles by means of an industrial vacuum cleaner. The surface must be clean, free from grease and oil and should be dry with the maximum substrate moisture content of < 4% by weight. The surface to be bonded must be level, with no irregularities or protrusion > 0.5 mm. Larger deviations must be leveled with QUANTOM® EPR 311. The adhesive tensile strength of the substrate being strengthened must be at least 1.5 MPa. All corners of the structure must be rounded to a radius of 20 mm.

Mixing: Consult QUANTOM® EPR 3301 or QUANTOM® EPR 3001 Product Data Sheet for information on epoxy resin.

Pre-mix each component. Mix entire unit, do not batch. Add contents of component B to component A. Mix thoroughly for 3 minutes with a mixing paddle on a low speed mixing drill (300-400rpm) until uniform in colour. Pour the mixed epoxy into a clean container and mix again for approximately 1 minute at low speed, keeping air entrainment to a minimum. Pot life starts with the mixing of both components A and B. At low ambient temperature it will be longer, at elevated temperatures it will be shorter. The larger the quantity of mixed material, the shorter the pot life.

Application: Cut the fabric to the desired length. Then apply the mixed QUANTOM® EPR 3001 or QUANTOM® EPR 3301 epoxy resin directly onto the prepared substrate at a quantity of 1.0 to 1.2 kg/m2 depending on the surface profile, using a trowel, brush or spatula. Carefully place the fabric onto the resin coating in the required direction with gloved hands and smooth out. Work out any irregularities or air pockets with a plastic spatula or laminating roller. Let the resin squeeze out between the rovings of the fabric. If more than one layer of fabric is required, apply additional QUANTOM® EPR 3001 or QUANTOM® EPR 3301 (0.8 to 1.0 kg/m2) within 60 minutes at 20°C after the application of the previous layer.

If the waiting time exceeds 60 minutes at 20°C , wait 12 hours before continuing the lay-up process. Then repeat as above.

At low temperatures and/or high relative humidity it may be longer than 12 hours for the surface may become slightly tacky. Before laying up another layer of fabric, the tackiness must be removed. This can be accomplished by washing the surface with a wet sponge or rinsing with water.

To add cementitious top coat systems to the cured epoxy, apply an additional layer of epoxy (15-20 mils) and blind (broadcast) the surface with silica sand to promote adhesion before coating.

Clean Up

Ventilate area. Confine spill. Collect with absorbent material. Dispose of in accordance with current, applicable local, state and federal regulations. Uncured material can be removed with approved solvent. Cured material can only be removed mechanically.

Limitations

- Overlapping of the fabric in the direction of the fibers must be 200 mm minimum.
- When placing fabric sheets side by side, overlapping is not necessary.
- Minimum substrate and ambient temperature 4°C .
- Ambient temperature must be 3°C above the Dew Point.
- Maximum service temperature is 60°C .
- Do not thin with solvents.
- Material is a vapor barrier after cure.
- Minimum age of concrete must be 21-28 days depending on curing and drying conditions.
- Prevent exposure of the strengthening system to direct sunlight.
- Protect the freshly applied resin from rain for a minimum of 12 hours.

Delivery

Dimensions: 100X0.5 m

Packaging Type: Roll

General technical data for QUANTOM® structural wrap systems

| Product name | Description | Thickness (MM) | Tensile strength(MPa) | Elastisity Modulus (GPa) | Elangation at break | Areal weight (Gr/M2) |
|--------------------|--------------------------------|----------------|-----------------------|--------------------------|---------------------|----------------------|
| QUANTOM®Wrap 300 C | High strength carbon UD fabric | 0.168 | 4950 | 235 | 1.9% | 304 |
| QUANTOM®Wrap 240 C | High strength carbon UD fabric | 0.135 | 4950 | 235 | 1.9% | 243 |
| QUANTOM®Wrap 200 C | High Modulus carbon UD fabric | 0.112 | 4950 | 235 | 1.9% | 202 |
| QUANTOM®Wrap 150 C | High Modulus carbon UD fabric | 0.084 | 4950 | 235 | 1.9% | 151 |
| QUANTOM®Wrap 300 A | Armid UD fabric | 0.210 | 2800 | 110 | 2.0% | 300 |
| QUANTOM®Wrap 300 B | Basalt UD fabric | 0.330 | 4000 | 100 | 3.1% | 300 |
| QUANTOM®Wrap 600 G | E-glass UD fabric | 0.236 | 2300 | 90 | 3.9% | 600 |
| QUANTOM®Wrap 400 G | E-glass UD fabric | 0.157 | 2300 | 90 | 3.9% | 400 |
| QUANTOM®Wrap 200 G | E-glass UD fabric | 0.078 | 2300 | 90 | 3.9% | 200 |